

Get to Know Your Walt®

SOS

Hold for 3 seconds to send emergency alert.

PUSH-TO-TALK (PTT)

Hold until you hear a chirp before relaying message.

VOLUME

Choose from **8 volume levels**.

BACK BUTTON

Press repeatedly to return to the menu screen.

TOUCHSCREEN

2.83-inch LCD screen with Gorilla® Glass technology

ACTIVE/FAVORITE CHANNELS

The blue-highlighted channel is where your PTT message will be sent. Your favorite channels will be locked at the top.

POWER BUTTON/SELECT

Press once to select **OR** press and hold for 2 second to put device to sleep.

NAVIGATION

Glove-friendly movement through screens.



Create a Channel

You can create new channels to talk to individuals or groups.

- 1 Tap the back button until you're on the menu screen and select **New Channel**.
- 2 Select **Individual** or **Group**.
- 3 Search for users using different options.
- 4 Tap a name to add to the channel.
- 5 Once you create the channel, **push the PTT button until you hear a chirp** & send your first message.



Radio Scan

Customize the channels you listen to!

- 1 **ALL** - Hear live audio from all unmuted channels when someone uses Push-To-Talk (PTT).
- 2 **OFF** - Turns scanning off. Only the active (blue) channel will play audio.
- 3 **FAVORITES** - Scans your unmuted favorites, plus the channel you're currently focused on.



Select Language

You can change your language by opening the menu, selecting Settings, then Profile Settings, and finally Change Language.



Utility Bar

Gain **quick and easy** access to the camera, add the channel to your favorites, and more settings at the bottom of your channel.



Still Need Help?

Contact your weavix Champion or go to the menu page to start a support ticket.